Contact Progressive Power & Control

Local phone: 317-849-5115

Toll-free phone: 800-875-5196

Fax: 317-849-5255

Email: info@progressivepower.net

Business Hours: PPC is open from 8am to 5pm (EST) Monday through Friday, excluding major holidays.

CAUSE	Pump Making Noise	No System Pressure	Breakage of Internal Parts	External Oil Leakage	Pump Not Pumping	Excessive Wear	Heating (Power Unit)	Heating (System)	Erratic Action
Restricted Inlet	✓					✓			✓
Air Leaks	✓					✓			
Air Entrainment	✓		✓		✓	✓	✓		✓
Reservoir Air Vent Plugged	✓								✓
Incorrect Pump Rotation/Speed	✓		✓	✓	✓				
Dirty/Small Filter/Strainer	✓		✓						
Pump Out of Line with Motor	✓	✓	✓						
Loose/Faulty Head Gasket	✓	✓	✓						
Cavitation	✓	✓	✓						
Pump Malfunction	✓	✓	✓		✓	✓	✓		✓
Relief Valve Not Functioning		✓					✓		✓
Dirt in Pump	✓	✓	✓		✓	✓			
Fluid Contaminated	✓								✓
Restricted Lines									✓
Pilot Pressure Too Low								✓	✓
Loosened Fittings				✓			✓		
Line Breakage		✓						✓	
Oil Velocity too High	✓		✓		✓		✓		
Oil Velocity too Low						✓		✓	✓
Pump Head too Tight			✓						
Stuck Pump Vane	✓	✓						✓	
Incorrect Control Valvo Setting		✓							
Internal Leakage in valves, cylinders or pumps		✓				✓	✓	✓	
Excessive Pressure above maximum pump rating			✓			✓			✓
Low fluid level in Reservoir			✓		✓	✓		✓	
Packing Worn/ Damaged				✓					✓
Oil Cooler Clogged						✓	✓		
Reservoir too Small	✓		✓		✓	✓		✓	
Valve Deposits								✓	
Electrical Solenoid Problems								✓	
Dried or Seal or O-rings	✓							✓	✓

Progressive Power and Control